

The pioneer in Korean dental implants is now working with the world !
www.cowellmedi.com



REMOVAL KIT



CWM
Cowellmedi Co., Ltd.


COWELLMEDI IMPLANT SYSTEM

Removal Kit (KCR001)


This product has tools for the safe and quick removal of fractured abutments or screws.




Abutment Removal Driver



Guide



Slot Driver



Screw Removal Driver



Tap Repair Driver



Machine Adapter




Abutment Removal Driver For fractured two-pieces type abutments

> When the abutment connection part is fractured and cold-welded, join the abutment removal driver in the forward direction to the connection part, and remove it by pulling it up (mallet technique applicable).


> KART01 : For removing M1.6 screws (Applicable to : Sub. Octa. type)

> KART02 : For removing M2.0 screws (Applicable to : Sub. Hex. type)

Diameter	Ø2.2	Ø2.6
	KART01	KART02



Tip



Screw Removal Driver For removing the screw fractured in the fixture

> Used when the coping screw or one-piece abutment screw is fractured, or when the screw is fractured in the fixture and cannot be removed.


> Join the guide to the fixture, and turn the screw removal driver counterclockwise for removal.

> Guide is not applicable to the types other than the sub type.

> KSR16 : For removing M1.6 screws (Applicable to : Sub Octa. / Ext Mini Type)

> KSR20 : For removing M2.0 screws (Applicable to : Sub. Hex. / Int. / Ext. Regular / Ext. Wide(Hex 2.7) Type)

Diameter	Ø1.1	Ø1.5
	KSR16	KSR20




Screw Tap Repair Driver

For the regeneration of damaged thread in the fixture

- > Used to regenerate the damaged thread in the fixture.
- > Join the guide to the damaged fixture, and regenerate the thread using the tap repair driver (Forward direction).
- > KTR16 : For regeneration when the screw in the M1.6 Fixture has been damaged.
- > KTR20 : For regeneration when the screw in the M2.0 Fixture has been damaged.



Diameter	Ø1.6	Ø2.0
	KTR16	KTR20



Slot Driver

Used for fractured one-piece-type abutment, healing, damaged cover screw

- > KHD0827 : For fractured one-piece-type abutment.
- > KSD30 : For healing and damaged cover screw hex part.






Guide

Serves as a guide for the screw removal driver and screw repair driver

- > KSRG16 : Applicable to : Sub. Octa. type
- > KSRG20 : Applicable to : Sub. Hex. type

Diameter	Ø2.9	Ø3.3
	KSRG16	KSRG20



Machine Adapter

Required when used with a machine type ratchet

