

The pioneer in Korean dental implants is now working with the world !
www.cowellmedi.com



Mini Plus IMPLANT




CWM
Cowellmedi Co., Ltd.

COWELLMEDI IMPLANT SYSTEM

Cement Type

DESIGN OF MINI PLUS FIXTURE

- > For mandible anterior spaces and edentulous arch
- > For temporary implants that supports permanent fixtures
- > Ø2.0 is recommended for temporary use, while Ø2.5, Ø3.0, Ø3.3 can be used as permanent implants



Implant


Diameter Cuff Length	Ø2.0	
	2.0mm	4.0mm
10mm	AMC1210S	AMC1410S
12mm	AMC1212S	AMC1412S
14mm	AMC1214S	AMC1414S
16mm	AMC1216S	AMC1416S
18mm	AMC1218S	AMC1418S

Diameter Cuff Length	Ø2.5	
	2.0mm	4.0mm
10mm	AMC2210S	AMC2410S
12mm	AMC2212S	AMC2412S
14mm	AMC2214S	AMC2414S
16mm	AMC2216S	AMC2416S
18mm	AMC2218S	AMC2418S

Diameter Cuff Length	Ø3.0	
	2.0mm	4.0mm
10mm	AMC3210S	AMC3410S
12mm	AMC3212S	AMC3412S
14mm	AMC3214S	AMC3414S
16mm	AMC3216S	AMC3416S
18mm	AMC3218S	AMC3418S

Diameter Cuff Length	Ø3.3	
	2.0mm	4.0mm
10mm	AMC4210S	AMC4410S
12mm	AMC4212S	AMC4412S
14mm	AMC4214S	AMC4414S
16mm	AMC4216S	AMC4416S
18mm	AMC4218S	AMC4418S

Impression Coping / Lab Analog




Impression Coping

- > Impression coping is taken by shoulder on Abutment, and, after impression taking, it is taken with Lab Analog to be able to make model of oral cavity.
- > But, Impression taking by immediate pulling method is available when abutment is removed.

Lab Analog

- > When top portion is altered, same adjustment must be made for lab analog.

Protect Cap




- > Provides temporary protection of mucogingiva and tongue after implantation.

Diameter Length	Ø4.0
7mm	AMCC001
9mm	AMCC002
11mm	AMCC003

Ball Type DESIGN OF MINI PLUS FIXTURE

> Temporary and Permanent solutions Over Denture patients



Implant

Diameter Cuff Length	Ø2.5	
	2.0mm	4.0mm
10mm	AMB2210S	AMB2410S
12mm	AMB2212S	AMB2412S
14mm	AMB2214S	AMB2414S
16mm	AMB2216S	AMB2416S
18mm	AMB2218S	AMB2418S

Diameter Cuff Length	Ø3.0	
	2.0mm	4.0mm
10mm	AMB3210S	AMB3410S
12mm	AMB3212S	AMB3412S
14mm	AMB3214S	AMB3414S
16mm	AMB3216S	AMB3416S
18mm	AMB3218S	AMB3418S

Socket



BATC002

> This is taken by shoulder on Abutment, and, after impression taking, it is taken with Lab Analog to be able to make model of oral cavity.

Impression Coping / Lab Analog



Impression Coping
AMBI001



Lab Analog
AMBL001

Impression Coping

> Impression Coping is used for impression taking of Ball Post.


Lab Analog

> When top portion is altered, same adjustment must be made for lab analog.


SURGICAL KIT [KMA003]




Point Drill




Ø1.3 Twist Drill



Ø1.8 Twist Drill



Ø2.3 / Ø2.6 Twist Drill



Driver

Cement Type

Machine KMDC31L


Ratchet KRDC19L

Ball Type


Machine KMDB27L

Ratchet KRDB19L


Tissue Punch *Extra product



Multi Gauge *Extra product



Drill Sequence



※ In case of D4 Bone quality, make proper adjustment in drilling. Due to narrow diameter, Mini PLUS Implants have self-tapping characteristic.

Clinical Application using Mini plus Implant

